

Item No.	Description
	AP-Attachment
125839900	Paralleling mandrel for AP + AP Micro 45°
125849900	Paralleling mandrel for AP + AP Micro 90°
509	AP female, HFA, single
509A	AP-impression female, brass
509PI	AP-male Pt/Ir., single
509T	AP-male titanium, single
512/1KT	Titanium-AP 90°, female HFA with retention for plastic
512/1T	Titanium-AP-attachment 90° compl. female HFA
512KT	Titanium-AP 45°, female HFA with retention for plastic
512T	Titanium-AP-Attachment 45° complete female HFA
514/1T	AP-male 90° titanium, single
514/1TU	AP-male 90° titanium, outsize + 0,10
514A	Impression-male, brass for AP + AP-Micro
514I	AP long, inactive
514T	AP-male 45° titanium, single
514TU	AP-male 45° titanium, outsize + 0,10
516	AP-cone, INOX, single
516K	AP-cone, Inox, to be soldered and for anchorage in plastic
516PI	AP-Cone, Pt/Ir., single, castable to titanium
516T	AP-cone, titanium, single
518	AP-cone-Plier
517/1T	Titanium-AP 90°, plastic female, complete
517KT	Titanium-AP 45°, plastic female, castable to plastic
517T	Titanium-AP 45°, plastic female, complete
517/1KT	Titanium-AP 90°, plastic female, castable to plastic
531	AP-screwdriver for activating
531/1	AP-screwdriver for cone-screw
532	AP-activating screw for male
532/2	AP-activating screw for male head diameter +0,5
532/3	AP-activating screw for male head+thread diameter +0,05
532/4	AP activating screw for male head+thread diameter + 0,10
533	AP cone-screw, single
535	AP-stepped bur
536	AP cone-space maintainer for adhesive technics
539	Soldering aid
540	Brass electrode for AP
541	Ceramic-spacer for AP + AP Micro
	AP-Micro
509/3M	Micro-AP female plastic, single
509M	Micro-AP female HFA, single
509MA	Micro-AP impression-female, brass
509MPI	Micro-AP female Pt/Ir., single

Item No.	Description
509MT	Micro-AP female titanium, single
512/1MKT	Titanium Micro-AP 90°, female HFA, with retention for plastic
512/1MT	Titanium-Micro-AP-attachment 90°, female HFA, complete
512MKT	Titanium-Micro-AP 45°, female HFA, with retention for plastic
512MT	Titanium-Micro-AP-attachment 45°, female HFA, complete
514/1MT	Titanium-Micro-AP male 90°, single
514/1MTU	Titanium-Micro-AP male 90°, outsize + 0,10
514MI	AP Micro, inactive
514MT	Titanium-Micro-AP male 45°, single
514MTU	Titanium-Micro-AP male 45°, outsize + 0,10
516M	Micro-AP-cone, INOX, single
516MK	Micro-AP-cone to be soldered and for anchorage in plastic
516MPI	Micro-AP-cone, Pt/Ir., single
516MT	Micro-AP-cone, titanium, single
517/1MKT	Titanium-Micro-AP 90°, female plastic, w. retention for plastic
517/1MT	Titanium-Micro-AP-attachment 90° female plastic, complete
517MKT	Titanium-Micro-AP 45°, female plastic, w. retention for plastic
517MT	Titanium-AP-Micro-attachment 45°, female plastic, complete
531M	Micro-AP screwdriver for activating
536M	AP-Micro cone-space maintainer for adhesive technics
539M	Micro-AP soldering aid
	AP-Piccolino
127829900	AP-Piccolino paralleling mandrel
509/3P	AP-Piccolino-female plastic, single
509P	AP-Piccolino-female HFA, single
509PA	AP-Piccolino-impression female brass
509PPI	AP-Piccolino-female, Pt/Ir., single
509PT	AP-Piccolino-female titanium, single
512P	AP-Piccolino-attachment female HFA, complete
514P	AP-Piccolino-male titanium, single
514PA	AP-Piccolino impression-male brass
514PI	AP-Piccolino, inactive
514PU	AP-Piccolino-male titanium, outsize + 0,10
516P	AP-Piccolino-cone, INOX, single
516PPI	AP-Piccolino-cone, Pt/Ir., single
516PT	AP-Piccolino-cone titanium, single
517P	AP-Piccolino-attachment, female plastic, complete
531/1P	AP-Piccolino screwdriver for cone-screw
532/2P	AP-Piccolino-activating screw for male, head diameter + 0,05
532/3P	AP-Piccolino-activating screw for male-head diameter + 0,10
532P	AP-Piccolino-activating screw for male
533P	AP-Piccolino-cone-screw, single
535P	AP-Piccolino-stepped bur
536P	AP-Piccolino-cone-space maintainer for adhesive-technic
539P	AP-Piccolino soldering aid
540P	Brass-electrode for AP-Piccolino

Item No.	Description
541P	ceramic-spacer for AP-Piccolino
	AP- Piccolino LV
124839900	Paralleling mandrel for AP Piccolino LV 45°
124849900	Paralleling mandrel for AP-Piccolino LV 90°
504PLV	AP-Piccolino LV-paralleling mandrel
509/3PLV	AP-Piccolino LV-female plastic, single
509PALV	AP-Piccolino LV-impression female, brass
509PLV	AP-Piccolino LV-female HFA, single
509PLVPI	AP-Piccolino LV-female Pt/Ir., single
509PLVT	AP-Piccolino-female titanium, single
512/1PLV	AP-Piccolino LV 90° attachment female HFA, complete
512PLV	AP-Piccolino LV 45° attachment female HFA, complete
514/1PLV	AP-Piccolino-LV-male 90° titanium, single
514/1PLVU	AP-Piccolino-LV-male 90° titanium, outsize + 0,10
514PALV	Impression male brass for AP-Piccolino-LV
514PLV	AP-Piccolino-LV-male 45° titanium, single
514PLVI	AP-Piccolino-LV, inactive
514PLVU	AP-Piccolino-LV-male 45° titanium, outsize + 0,10
516PLV	AP-Piccolino-LV-cone, INOX, single
516PLVT	AP-Piccolino-LV-cone titanium, single
517/1PLV	AP-Piccolino-LV 90°, female plastic, complete
517PLV	AP-Piccolino-LV 45°, female plastic, complete
532/12PLV	AP-Piccolino-LV activating screw 45°, head diam. + 0,05
532/1PLV	AP-Piccolino-LV activating screw 45°
532/2PLV	AP-Piccolino-LV activating screw 90°, head-diam. + 0,05
532PLV	AP-Piccolino-LV activating screw 90°
536PLV	AP-Piccolino-LV cone-space-maintainer for adhesive technic
539PLV	AP-Piccolino-LV soldering aid
540PLV	Brass electrode for AP-Piccolino-LV
541PLV	ceramic spacer for AP-Piccolino-LV+AP-Piccol.-Micro-LV
532/13PLV	AP-Piccolino-LV activating screw 45°, head-diam. + 0,10
532/3PLV	AP-Piccolino-LV activating screw 90°, head-diam. + 0,10
	AP-Piccolino MLV
509/3MLV	AP-Piccolino-LV Micro female plastic, single
509MLV	AP-Piccolino-LV Micro female HFA, single
509MLVT	AP-Piccolino-Micro female titanium, single
512MLV	AP-Piccolino-LV Micro female HFA, complete
514MLV	AP-Piccolino-LV Micro male, single
514MLVU	AP-Piccolino-LV Micro male, outsize + 0,10
517MLV	AP-Piccolino-LV Micro female plastic, complete